




## Toucan Eco Active Plus Auto Installation Schematic

Ensure water input and power supply is  
in place before installation



Example of succesfull install

